



**An eLock Center and eLOCK Mobile system check is performed before you productively use the eLOCK System.**

**The system check ensures that all components are checked for faultless function immediately after a setup or a service pack is installed.**

| <b>A Equipment Required</b> |   |  |
|-----------------------------|---|--|
| 1                           | PC as per system requirements                       | -> Data source (DVD, USB stick, download) current release  |
| 2                           | eLock software                                      | -> WIN System device manager without error message   |
| 3                           | PDA (incl. docking station and power supply unit)   | -> WIN System device manager without error message   |
| 4                           | CFA (if necessary cable)                            |  |
| 5                           | 2 fittings  | -> depersonalised  |
| 6                           | 2 identifiers                                       | -> depersonalised  |
| 7                           | 1 master  | -> depersonalised  |
| <b>B Start</b>              |   |  |
|                             |   | <b>Check</b>   |
| 1                           | eLock Center installed                              | -> Data source (DVD, USB stick, download) current release  |
| 2                           | Programming station connected                       | -> WIN system control device manager hardware ok   |
| 3                           | Docking station connected - PDA plugged in          | -> Activ Sync profile settings -> "Connected" message  |
| 4                           | eLOCK Mobile installed                              |  |
| <b>C System check</b>       |   | <b>Check - planned result</b>  |
| 1                           | Start eLock Center (without licensing)              | -> ? - Info -> Version = DeltaLog  |
| 2                           | Create DEMO clients                                 | = DB is created;   |
| 3                           | Change clients                                      | = Demo client starts<br>Hardware version and firmware version  |
| 4                           | PDA -> connect CF adapter                           | -> Main menu -> Help -> system information<br>= up-to-date firmware and hardware   |
| 5                           | Programming station <-> eLockCenter Comport         | -> Extras-Settings-Hardware = COM xy   |
| 6                           | System definition (ES7000/ ES5000)                  | -> Extras-Settings-System<br>= ES7(ES5) / 40000 IT (60000 IT)  |
| 7                           | Program master                                      | = Master sets fitting in programming mode  |
| 8                           | Fitting 1 and 2 with <> Create Protection Zone      | = Protection zone can be assigned  |
| 9                           | Synchronise PDA                                     | -> Connection successfully made<br>-> Stock -> Selection of fittings offered<br>-> List View Personalise Jobs listed                     |
| 10                          | Start eLOCK Mobile                                  | -> Start Screen -> Version = DeltaLog  |
| 11                          | Personalise Fitting 1 and 2                         | = Personalise fitting<br>= Data transfer Air Interface and/or Wire ok  |
| 12                          | Read fitting info                                   | = Fitting personalised; current time   |
| 13                          | Program IT 1 and 2 with Person and Group of Persons | = IT 1 & 2 programmed without error message  |
| 14                          | Read IT info  | = IT data corresponds to DB data   |
| 15                          | Activate IT 1 and 2 with fitting via cross          | = Fitting 1 -> IT 1 opens IT 2 does not open<br>= Fitting 2 -> IT 2 opens IT 1 does not open   |
| 16                          | Reset system components                             | -> Place IT on the PS and delete<br>-> Delete PDA fitting<br>-> Place Master on the PS and delete<br>-> Administration - Client - Delete |

*Thank you for your cooperation.*